

## MAG250 PROGRAMABLE REMOTE CONTROL

(Instructions for programming)

Provided MAG250 remote control was created for Your easy and comfortable use. It has possibility to be programmed for different devices and can control Your TV and MAG250 at the same time.

This remote control has two LED indicators. Green one indicates simple control mode, while red indicates programming mode of the buttons on the additional section of the remote control.

Programming of this remote control is based on copying signal of another remote control:

1. Press "TV SET" button and hold it for 2s. Remote control is in programming mode(ready) when red indicator starts shine brighter (not blinking)
2. Red indicator starts blinking when you press button you want to assign a new function.
3. Place both remote controls (for example TV's and MAG250's) as close as possible, with both IR transmitters directed to each other and press the button of the remote you want to copy from. Hold it for about 2 s.
4. After red indicator is on (not blinking), you can program other buttons.
5. Press "TV SET" for finishing and saving your setup.

